


# 6 Foot Cambridge Park Bench w/ Arms


For Fastener Pack  
(FP-CB6BA-CU-02)



Congratulations !!

You have just purchased the finest recycled plastic  
park bench available. Enjoy !!!

Before assembly, please make sure all components are included.



( 2 ) - Two Arms  
BSA-CBA-01


E - Arm

E - Arm




( 1 ) - One Fastener Pack  
FP-CB6BA-CU-02


FP - Fastener Pack



D - Bench End



D - Bench End



D - Bench End

( 3 ) - Three Bench Ends  
PS-CBBE-C-01

. .	A - Bull Nose Bench Board	. .	. .
. .	A - Bull Nose Bench Board	. .	. .

( 2 ) - Two Bull Nose  
Bench Boards  
BP-CB6B-A-02

. .	B - Bench Board	. .	. .
. .	B - Bench Board	. .	. .
. .	B - Bench Board	. .	. .
. .	B - Bench Board	. .	. .
. .	B - Bench Board	. .	. .
. .	B - Bench Board	. .	. .

( 6 ) - Six Bench Boards  
BP-CB6B-B-02

. .	C - Bull Nose Bench Board w/ Arm Holes	. .	. .
. .	C - Bull Nose Bench Board w/ Arm Holes	. .	. .


( 2 ) - Two Bull Nose  
Bench Boards  
w/ Arm Holes  
BP-CB6BA-A-02  
FS-CB6BA-CAP-02

Before assembly, please make sure all fasteners are included.


60 - #12 x 1 1/2" Pan Head Phillips Screw



4 - 1/4" x 3" Hex Head Lag Bolt



4 - 1/4" Flat Washer





Also needed for this assembly will be the following materials:

1 - #3 Phillips Drive Bit

1 - 7/16" Socket Wrench

**Fig #1:**

In order to make the assembly of this Cambridge Bench easier while going through the assembly process the board positions are numbered and will be referenced in later steps.




**Note:**

Stand bench ends flat on ground. View is only to show detail.

**Step #1:**

Stand (1) One bench end upright and place (1) One bull nose bench board (A) on position 1 being sure to align the pilot holes to the pre-drilled holes in the bench end. After the holes are properly aligned, fasten with (1) One #12 x 1 1/2" Pan Head Phillips Screw in the pre-drilled hole on the right side of the bench end.

Note: Do not tighten screw completely. This will be done in a later step.



### Step #2:


Stand the other (2) Two bench ends upright, one at a time, and place the bull nose bench board (A) already attached to the first bench end, on position 1 being sure to align the pilot holes with the pre-drilled holes in the bench end. After the holes are properly aligned, fasten with (1) One #12 x 1 1/2" Pan Head Phillips Screw in the pre-drilled hole on the right side of the bench end.

Note: Do not tighten screws completely. This will be done in a later step.

### Step #3:


Align the pilot holes on the bull nose bench board (A) to the pre-drilled holes on the left side of the bench ends. After the holes are properly aligned, fasten with (1) One #12 x 1 1/2" Pan Head Phillips Screw per bench end.

Note: Be sure to tighten screws completely after this step.




### Step #4:

Place a bull nose bench board (A) on position 5. Repeat Steps 1 - 3 to attach. Use (1) One #12 x 1 1/2" Pan Head Phillips Screw per hole to fasten.




### Step #5:

Repeat Steps 1 - 3 to attach bull nose bench boards w/ arm holes (C) on positions 4 & 10. Use (1) One #12 x 1 1/2" Pan Head Phillips Screw per hole to fasten with the exception of the arm holes.



**Step #6:**

Repeat Steps 1 - 3 to attach bench boards (B) on positions 2, 3, 6, 7, 8 & 9.  
Use (1) One #12 x 1 1/2" Pan Head Phillips Screw per hole to fasten.



**Step #7:**

Align the pilot holes on the Arm to the pre-drilled holes on the bullnose bench boards w/ arm holes (C). After the holes are properly aligned, fasten with (1) One 1/4" Flat Washer and 1/4" x 3" Hex Head Lag Bolt per hole to fasten.