


FS-CNT-CAP-01






IMPORTANT NOTICE:




 USE A DRILL WITH ADJUSTABLE TORQUE FOR BEST RESULTS.
OVER-TIGHTENING WILL RESULT IN STRIPPING OUT THE PILOT HOLE, AND SCREW WILL "SINK" INTO THE PLASTIC WHICH MAY CAUSE A STRESS FRACTURE OR THE SCREW MAY POKE THROUGH THE TOP OR SEAT.



Step #1:

Slide (1) One Table Center (R) onto each end of the Table Leg (H) as shown above. Use (1) One $3/8" \times 4 1/2"$ Hex Head Bolt and (1) One 3/8" Flat Washer along with (1) One 3/8" Flat Washer and (1) One 3/8" Nylon Lock Nut per hole to secure.


Do not tighten bolts completely. This will be done in a later step.



Step #2:

Slide the remaining (3) Three Table Legs (H) in to the Table Centers (R). Use (1) One $3/8" \ge 41/2"$ Hex Head Bolt and (1) One 3/8" Flat Washer along with (1) One 3/8" Flat Washer and (1) One 3/8" Nylon Lock Nut per hole to secure.

Do not tighten bolts completely. This will be done in a later step.




Step #3:

Place the Table Top (J) upside down onto a piece of cardboard or another soft surface to protect it during installation. Place the leg assembly onto the Table Top as shown above. Align the pre-drilled holes in the Table Legs (H) with the pilot holes in the Table Top (J). Use (1) One #12 x 1" Pan Head Screw per hole to secure.

Be sure to tighten all screws and bolts after completing this step.


FS-CNT-CAP-01



Step #4:

While the table is upside down, align the pre-drilled holes in the Table Leg (H) to the pilot holes in the Seat Support (Q) as shown above. Use (1) One $\#12 \ge 1/2$ " Flat Head Screw per hole to secure.


Do not tighten screws completely. This will be done in a later step.



Step #5:

While the table is upside down, align the pre-drilled holes in the Seat (N) to the pilot holes in the Table Leg (H) as shown above. Use (1) One $#12 \times 1^{"}$ Pan Head Screw per hole to secure.

Do not tighten screws completely. This will be done in a later step.



Step #6:

While the table is still upside down, align the pre-drilled holes in the Seat (N) to the pilot holes in the Seat Support (Q) as shown above. Use (1) One #12 x 1-1/4" Flat Head Screw per hole to secure.

Be sure to tighten all loose screws after completing this step.

DEAR VALUED CUSTOMER,

THANK YOU FOR PURCHASING THIS PRODUCT. THIS PRODUCT IS MANUFACTURED USING RECYCLED MATERIALS AND MAY HAVE SLIGHT COLOR VARIATIONS, OCCASIONAL SPECKS OF COLOR OR IRREGULAR SURFACE PATTERNS. THESE ARE NORMAL CONDITIONS OF RECYCLED PLASTICS AND MAKE EACH PIECE OF FURNITURE UNIQUE. THESE CHARACTERISTICS DO NOT AFFECT THE STRENGTH, QUALITY OR PERFORMANCE OF THE PRODUCT.

THANK YOU AGAIN FOR PURCHASING THIS PRODUCT AND HELPING OUR ENVIRONMENT.